



PIN-CH® foot part for cantilever

PIN-CHSCRCS

Rectangular foot part for our flexible PIN-CH® system where you choose the foot part depending on floor surface and furniture design. The foot part is mounted in the foot holder with a click and removed with, for example, a screwdriver. Suitable for school chairs and other furniture with horizontal tubes.

Used together with foot holders **PIN-SCR** and **PIN-CS**.

The PIN-CH® system is based on the ability to easily replacing the foot part when it is worn out or when moving furniture to another floor surface. The components are marked to make it easier to find new parts.

Art. no	A	B	C	M1
PIN-CHSCR-CSS	69	17	5.5	⬟ POM

⬟ *Black RAL 9017*

Address Ackurat Industriplast AB
Värnamovägen 42
360 30 Lammhult
Sweden

Phone +46 (0)472 26 93 00
E-mail info@ackurat.se
Web ackurat.com