




PIN-CH® foot part for tube and wooden legs – angled, felted

PIN-CHAF

Angled foot part with felt for our flexible PIN-CH® system where you choose the foot part depending on floor surface and furniture design. The foot part is mounted in the foot holder with a click and removed with, for example, a screwdriver. The glide has a rotation stop ensuring that the foot part stays in place. Suitable for chairs, among other things, and is available in several angles and sizes.

Used together with foot holders [PIN-T](#) (tube) and [PIN-W](#) (wood).

The PIN-CH® system is based on the ability to easily replacing the foot part when it is worn out or when moving furniture to another floor surface. The components are marked to make it easier to find new parts.



Art. no	A	C	D	M1	M2
PIN-CHAF141218S	14	12-18	8	◆ POM	Wool felt
PIN-CHAF141822S	14	18-22	8	◆ POM	Wool felt
PIN-CHAF14612S	14	6-12	8	◆ POM	Wool felt
PIN-CHAF161218S	16	12-18	8	◆ POM	Wool felt
PIN-CHAF161822S	16	18-22	8	◆ POM	Wool felt
PIN-CHAF16612S	16	6-12	8	◆ POM	Wool felt
PIN-CHAF181218S	18	12-18	8	◆ POM	Wool felt
PIN-CHAF181822S	18	18-22	8	◆ POM	Wool felt
PIN-CHAF18612S	18	6-12	8	◆ POM	Wool felt
PIN-CHAF191218S	19	12-18	8	◆ POM	Wool felt
PIN-CHAF191822S	19	18-22	8	◆ POM	Wool felt

Art. no	A	C	D	M1	M2
PIN-CHAF19612S	19	6-12	8	🏠 POM	Wool felt
PIN-CHAF201218S	20	12-18	8	🏠 POM	Wool felt
PIN-CHAF201822S	20	18-22	8	🏠 POM	Wool felt
PIN-CHAF20612S	20	6-12	8	🏠 POM	Wool felt
PIN-CHAF251218S	25	12-18	8	🏠 POM	Wool felt
PIN-CHAF251822S	25	18-22	8	🏠 POM	Wool felt
PIN-CHAF25612S	25	6-12	8	🏠 POM	Wool felt
PIN-CHAF281218S	28	12-18	8	🏠 POM	Wool felt
PIN-CHAF281822S	28	18-22	8	🏠 POM	Wool felt
PIN-CHAF28612S	28	6-12	8	🏠 POM	Wool felt

🏠 Black RAL 9017