



PIN-CH® foot holder for sled base chair – horizontal wire/tube

PIN-S

Horizontal foot holder for our flexible PIN-CH® system for straight tubes or wire, where the foot part is selected based on the surface and design. The foot holder is mounted with a screw, and the foot part clicks into the foot holder and can be removed using, for example, a screwdriver. ideal for sled chairs and other furniture with horizontal tubes or wire.

Note: *Install using screws with a flat underside on the screw head.*

Used together with **PIN-CHSC** and **PIN-CHSCF**.

The PIN-CH® system is designed to make it easy to replace the foot part when it becomes worn or when moving a piece of furniture to a different surface. The components are marked to make it easier to find replacement parts.

rPA = Recycled

Art. no	A	B1	B2	C1	C2	C3	C4	D	M1
PIN-S1011S	10-11	16	38.5	5	10	3.5	1	5.5	▲ rPA
PIN-S1011T	10-11	16	38.5	5	10	3.5	1	5.5	⊘ PC
PIN-S1213S	12-13	16	38.5	5	10	3.5	1	5.5	▲ rPA
PIN-S1213T	12-13	16	38.5	5	10	3.5	1	5.5	⊘ PC
PIN-S1416S	14-16	16	38.5	5	10	3.5	1	5.5	▲ rPA
PIN-S1416T	14-16	16	38.5	5	10	3.5	1	5.5	⊘ PC

▲ *Black* ⊘ *Transparent*

Address Ackurat Industriplast AB
Värnamovägen 42
360 30 Lammhult
Sweden

Phone +46 (0)472 26 93 00
E-mail info@ackurat.se
Web ackurat.com